



P/N: 50-13-1M09-216 (REV. A)

Description: N Right Angle Male Crimp for RG214 Cable




**STEP 1**

- a. Slide the Heatshrink Sleeve onto the cable (option).
- b. Slide the Crimp Ferrule onto the cable.
- c. Strip the cable according to the dimensions as below.




**STEP 2**

- a. Fan the braid.
- b. Slide the cable into the Main Body.
- c. Solder the cable's inner conductor.




**STEP 3**

- a. Slide the Crimp Ferrule over the braid.
- b. Crimp the Crimp Ferrule with Crimping tool (10.9 [.429] HEX.).



**STEP 4**

- a. Put the Gasket into the Main Body.
- b. Screw the Back Nut onto the Main Body.
- c. Cut the excess of braid if necessary.
- d. Slide the Heatshrink Sleeve over the Crimp Ferrule and heatshrink it in place (option).



Note: Dimensions in millimeters (mm).